

FITTING INSTRUCTIONS FOR EUROPA GRADED SAFES

- Move the safe into it's chosen position.
- Mark the floor or wall through the base or rear fixing hole(s).
- Move the safe out of position. Using a 25mm drill bit, drill a hole 120mm deep at the point(s) marked.
- Unscrew the rawl shield from the bolt provided and insert the rawl shield into the hole(s) you have drilled.
- Move the safe back into position over the rawl shield and insert and tighten the fixing bolt using a 14mm allen key.
- Insert the plastic cover supplied into the hole/s.
- When this is complete, your safe is now ready for use.
- Grade 3, 4 & 5 (EN1143) – for alarm cable entry, drill through filler plug and inner skin 8mm drill. For re-installation without alarm cable, external hole to be re-filled with body filler.