Hotelsafe saga LTP

Always read the manual carefully before you start using the safe.





How to open your safe for the first time

To open your safe for the first time you will have to enter the factory code: **1 2 3 4** followed by **#** or **LOCK**.

How to close your safe

To close your safe you will have to enter a 4-digit code followed by **#** or **LOCK**.

For example: 1 2 3 4 # or LOCK

When you want to open your safe the next time you will have to enter the code you have used to lock the safe the last time.

How to change your code

When you want to change your code we always advise to do this with the door open.

First you will have enter the current code to unlock the lock.

Now you can enter the new 4-digit code followed by `#'.

Your new code is set now.

How to use your emergency key

Use a hex key to remove the screws from the golden cover.

Put your key in this hidden key hole and turn the key to the left to open the safe.

Now press * **1 2 3 4** # or **LOCK** to program your new code.

Now you can take out the emergency key.

Please make sure to $\underline{\textbf{not}}$ store the emergency key inside the save.

Opening the safe with the master code

If the master code is needed you can contact De Raat. Please call 079 – 363 4881 or mail to service@deraat.nl

Checking the batteries

Press `#'.

When the screen shows: 'BA-HI' it is not needed to replace the batteries yet.

When the screen shows: 'BA-LO' it is necessary to replace the batteries.

What does it mean?

Below an explanation of all the signals your safe can give you:

AGAIN: You will have to enter your code one more time

BA-HI: The batteries have enough voltage.

BA-LO: You will have to change the batteries.

CLOSE: The lock is closed.

DONE: The procedure has been completed.

NEW: The new numbers have to be entered one more time.

OPEN: The lock is opened and you can open your safe.

